

# User Instructions VMax Adapter

For use with the i-Series Portable Dehumidifier

The VMax Adapter directs the warm, dry air produced by the i-Series dehumidifiers directly over the floor surface in a focused, laminar flow to help accelerate drying.

# READ AND SAVE THESE INSTRUCTIONS

#### **KEY FEATURES**

- Rotomolded polyethylene construction same durable material as the i-Series housing.
- Ridged mounting ring fits easily over i-Series outlet duct ring.
- Also works with the Sahara Snout Adapter Kit (F201).

### **SETTING UP THE VMax**

- 1. Place the VMax on the floor in front of the i-Series outlet duct ring, as shown in Fig. A.
- 2. Slide the VMax over the ring until it rests snugly against the base of the duct mounting ring.

The VMax and i-Series unit are now ready for use.

#### **MAINTENANCE**

To maintain appearance, wipe interior and exterior surfaces with a damp cloth. For deep cleaning and a lasting, protective shine, use Dri-Eaz MicroGuard Cleaner and MicroGuard Protectant, available from your Dri-Eaz distributor.

## **WARRANTY**

Warranty information is available from your dealer.

For more information about the VMax, contact your dealer or call Dri-Eaz Products at 800-932-3030.

#### FIG. A: OPERATING POSITION

Place VMax on the floor in front of the i-Series dehumidifier and slide into position over the duct ring.

